




COMPONENT LAYOUT FOR 6127

0 1 11 5 15 0

A diagram showing a horizontal reference length of 3 ft. A grommet is shown on the right side of the reference length. A dimension line indicates a distance of 6" approx from the grommet to the right edge of the reference length. A note points to the grommet: "SEE NOTE 1 & 2".

1. ASSEMBLE GROMMET TO CABLE PRIOR TO WIRING, STRIP OUTER INSULATION TO DIM. SHOWN.
2. FOLD BACK ALL UNUSED WIRES AND TIE.



SIGNAL	WIRE NO. (REF.)	PIN NO. (REF.)
GKAO	1	1
GKA1	2	2
GKA2	3	3
GKA3	4	4
GKBO	5	5
GKB1	6	6
GKB2	7	7
GKB3	8	8
G15U	9	9
PRMS	10	10
GLPN	11	11
	12	12
	13	13
	14	14
	15	15
	16	16
	17	17
	18	18

SIGNAL	WIRE NO. (REF.)	PIN NO. (REF.)
	19	19
G10B0	20	20
G10B1	21	21
G10B2	22	22
G10B3	23	23
G10A0	24	24
G10A1	25	25
G10A2	26	26
G10A3	27	27
I0B1	28	28
	29	29
I0B3	30	30
Q150	31	31
	32	32
I0V	33	33
I0V	34	34
I0V	35	35
CK GND.	36	36

WANG LABORATORIES INC.			
TEWKSBURY, MASS.			
ORDER NO.	DRAWN	APP.	
714	F.S.S.	11-5-71	RAU
	CHECKED	APP.	
TITLE			
SCHEMATIC LOGIBLOC MARK SENSE CARD READER			
DR	DATE	NO.	
202	6	6127-1	10